

Embra End Cap-Storage with Coat Rack Installation

Tools Required

- 3/16" Hex Drive Allen Wrench

Hardware Required

- Coat Rack and Pole Assembly
- Storage Assembly
- Socket Drive Flat Head Cap Screw

Installation:

- Locate and unbox the two boxes containing the Coat Rack and Storage Assembly.

Install the Coat Rack:

1. The Coat Rack must be assembled prior to attaching the Storage Assembly to the Leg Frame,
2. Align Coat Rack assembly onto table and use the Flat Head Hex Drive machine screw. See Figure A

Note: Be sure to align the set screw to the back of the table and the coat hook to face forward and parallel to the front of the table. See Figure B

